



### **AGM C8 Corvette Carbon Fiber Gauge Cluster Bezel (FA5) Instructions:**

- 1:** Remove your OEM cluster bezel by unscrewing the single torx screw to the left of the steering wheel (use new part for reference).
- 2:** Gently pull the bezel away from the dash. It is held in with multiple clips, work them loose slowly.
- 3:** Now that you have both bezels (new and OEM) side by side, you'll need to remove the factory leather boot and transfer it to your new AGM Carbon Bezel. We recommend cutting the tab locks (melted plastic) from the OEM bezel so that we can reuse the boot. \*Note the location of the boot on the OEM bezel. Use the adhesive provided to secure the boot to your new carbon bezel.
- 4:** Transfer all OEM metal clips to new bezel.
- 5:** Reinstall into vehicle and enjoy!