



## 2020+ C8 Stingray Z06 Style Spoiler Instructions

- 1) Remove rear bumper using the instructions on the website. Also remove the third brake light from the bumper and set aside.
- 2) Place the supplied reinforcement bracket onto the rear chassis, being sure to align the center mark on the bracket to the center hole in the chassis. Pull the trunk carpet back so that you don't accidentally drill through it. Drill 4 pilot holes into the chassis using a 4mm drill bit (using the bracket as the template).



3) Remove the bracket and open the holes you just drilled to 8mm.

4) Remove the plastic tangs on the left and right side of your third brake light using a file. \*This step is not 100% necessary, but it helps to gain access to the spoiler bolts.



5) Place the bracket and third brake light into the bumper. See photo below for orientation.



6) Install your Z06 spoiler using the supplied M6 x 25mm bolts (x2) and large washers (x2).

7) Install the bumper back onto the car.

8) Install the OEM T15 torx top bumper flange mounting screws.

9) Pull back the trunk carpet and install the M6 x 16mm (x4) bolts and small washers (x4) into the bracket. (Leave these loose until all of the bumper mounting hardware is secure).

10) Install the remaining OEM hardware to secure the bumper.

11) Tighten the 4 M6 bumper bracket bolts.

12) GRAB A BEER, SIT BACK AND ENJOY!

