



### **AGM C8 Corvette Door Boomerang Installation:**

- 1) Remove contents from packaging
- 2) Dry fit door handle cover onto vehicles door. Slide the handle cover away from the door jam as far as it will go to make sure there is sufficient panel gap between handle and lower intake scoop when door is closed. Clean the mating surface with rubbing alcohol and prep for installation. Remove red 3M tape covering and install carbon cover onto handle. Repeat for opposite side.
- 3) Remove lower intake scoop. There will be (4) 8mm nuts holding each piece in place.
- 4) Dry fit covers on to scoop panel. Slide the cover away from the door jam edge as far as it will go so that there is sufficient panel gap between scoop and door handle. Clean the mating surface with rubbing alcohol and prep for installation. Remove red 3M tape covering and install carbon cover onto scoop. Reinstall scoop onto vehicle, adjusting as necessary for proper fitment. Repeat for opposite side.
- 5) ENJOY!