



## 2023+ C8 Z06 & ZR1 High Wing Spoiler Installation Instructions

- 1) Remove rear bumper using the instructions on our FAQ/Instructions page, [www.agmotorsports.net/faq-instructions](http://www.agmotorsports.net/faq-instructions)
- 2) Print out the “Driver and Passenger Top Bumper Cutout template from the AGM File Share Page, [www.agmotorsports.net/file-share/37c1e406-40e2-4f44-b908-a3b345c61585](http://www.agmotorsports.net/file-share/37c1e406-40e2-4f44-b908-a3b345c61585)



- 3) Detach the OEM low spoiler from the bumper by removing the 10 securing nuts and set it aside. Next, take out the taillights from the bumper and set them aside, too. This will make accessing the chassis in step 5 much easier.
- 4) Place the template from step 2 on your bumper, ensuring proper alignment. It's versatile for both sides—just flip it over. Trace the dark rectangle cutout area and the 2 M8 drill holes. Repeat on the other side. Use a small drill bit to make 4 corner holes in the rectangle on both sides of the bumper. Cut out the rectangle using a Dremel or a sharp utility knife, but take your time
- 5) Take the left and right upper spoiler mounts (shown in the photo) and secure them to the bumper using the supplied fasteners. Ensure the tallest part of the mounts faces rearward. Set aside the lower spoiler mounts and 4 M6 long bolts for use in step 6.



- 6) Reattach the bumper to the car temporarily. Take the left and right lower spoiler mounts, reach through the taillight holes, and loosely secure them to the upper mounts using the supplied 40mm and 60mm M6 bolts.
- 7) Position the left and right lower mounts flush to the chassis; they almost self-locate. While securely holding them, trace around the outside edges and mark the 3 drill holes. Remove the lower mounts and set them aside. Next, take off the rear bumper.
- 8) Using a ¼” drill bit, drill the 6 holes you traced (3 on each side) into the chassis. Then, take the left and right lower mounts and bolt them to the chassis.
- 9) Reinstall the taillights into the bumper and reattach the bumper to the car. Once the bumper is secured, grab the 2 40mm and 2 60mm M6 bolts. Secure the upper mounts to the lower mounts, with the 40mm bolts in the front and the 60mm bolts in the rear.
- 10) Attach your Z07 or ZR1 spoiler with the provided stainless Torx hardware and washers.
- 11) **Enjoy your new look and performance!**