

Loosely install the 2 outer bolts into the splitter (blue arrows). Lift the splitter up into position and install the center bolt which will align splitter into place. Lastly, install the remaining bolts and tighten securely.

