

- PASSENGER SIDE
- FLIP FOR USE ON DRIVER SIDE

- UPPER FRUNK PANEL TRIM TEMPLATE -

ALIGN TO CORNER OF PANEL



CUT THIS AREA OUT

