



2020+ C8 Corvette Carbon Fiber Diffuser Fins



Installation:

1. The large end of the diffuser fins matches the curvature of the lower pan.
2. The diffuser fin studs will mount to the lower diffuser grill using the supplied fasteners.
3. The inside fins use the OEM hardware on bottom side to locate and secure them.
4. The outside fins use the supplied hardware for install. Once installed to lower grill opening, drill holes in lower pan and secure using supplied hardware.