


Rear Wheel Opening Molding Replacement



Rear Wheel Opening Molding Replacement

| Callout | Component Name |
|---|--|
| Preliminary Procedure Tire and Wheel Removal and Installation | |
| 1 | Rear Wheel Opening Molding Bolt Caution: Refer to Fastener Caution . Tighten 2.5 (22 lb in) |

| Callout | Component Name |
|----------------|---|
| 2 | Rear Wheel Opening Molding Procedure Starting from the top use a trim type release tool to release the 5 spring clips. |